



## Warm RO Flush

Step 1. Remove Filter

Step 2. Disconnect Sap supply line and hook up warm (75° F/24° C Max.) RO supply.

Step 3. Relocate water and sap concentrate lines into warm RO container.

Step 4. Do a starting TDS (ppm) of RO water.

Step 5. Open up the restrictor (Flush Valve).

Step 6. After running the RO for one minute, measure the TDS of the warm RO water.

Note: If the TDS has more than tripled, dump the warm batch or add it to your sap storage.

Optional: Second Flush – repeat Steps 4 – 6.

\*Remember to put back in a filter when you are finished the flush.